

# **SOUTHWEST**

*Connecting you locally and around the world*

# **BROADBAND**

## **SW STREAM ROKU USER GUIDE**



*The information included in this document is correct at the time of release.*

*© 2025 Southwest Broadband, all rights reserved. Printed in the USA.*


*SW STREAM is a registered trademark of Southwest Broadband. All other trademarks are the property of their respective owners.*

## Table of Contents


<b>Installing the SW STREAM TV App.....</b>	<b>3</b>
<b>Main Menu.....</b>	<b>4</b>
<b>Introduction to Your TV Features .....</b>	<b>4</b>
<b>Getting Started with the Remote Control Main Features.....</b>	<b>5</b>
<b>TV Guide.....</b>	<b>5</b>
<b>Future Program Options in TV Guide .....</b>	<b>6</b>
<b>Restart TV that You Missed .....</b>	<b>6</b>
<b>Program Options While Watching TV .....</b>	<b>7</b>
<b>How to Record .....</b>	<b>8</b>
<b>Settings .....</b>	<b>8</b>
<b>Create Favorite Channel Lists .....</b>	<b>9</b>
<b>How to See Your Favorite Lists.....</b>	<b>9</b>
<b>Changing Your Favorite Lists .....</b>	<b>10</b>
<b>How to See the TV Guide with Your Favorite Lists.....</b>	<b>11</b>

## Installing the SW STREAM App

Make sure your Roku is connected to your home internet (Wi-Fi or wired ethernet). On the Roku Home screen, search for “swstream”. Select the “SW STREAM” app, as shown below. Add the app, then open it.




Log in with your username and password, then type in any device name you want. NOTE: You must use a unique device name for each Roku. Then select “Submit”. If you see an error, please confirm that you entered your login credentials correctly.



In a few moments, you will see a preview of the first channel in the lineup within the Main Menu as shown below.

## Main Menu



## Introduction to Your TV Features

Here are some of the main features available to you on SW STREAM.

- Record what you are watching live, record a program or series from the TV Guide that aired up to 24 hours ago, and schedule future recordings from the TV Guide
- From the Main Menu, you can see the weather in your area, view a list of programs on each channel available for restart, and go to Settings for creating favorite lists and parental controls.
- Go back up to 24 hours in your TV Guide to watch or record a program or add it to your favorite list.

# Getting Started with the Remote-Control Main Features




Key	Button	Action
1	"BACK"	3 Functions: 1) From full screen TV, displays Menu or TV Guide 2) In a menu screen, backs up one menu screen 3) From TV Guide, brings up your favorite lists
2	"UP / DOWN"	CH Up / Down
3	"HOME"	Exit to Roku Home screen
4	"OK"	Program Options while watching full screen TV
5	"ASTERISK"	Closed Captioning options

## TV Guide

Channel	Program	Time	Program	Time	Program	Time	Program	Time
2 TPT 2	Rosie's Rules	08/07 9:30 am	Sesame Street	10:00 am	Work It Out	10:30 am	Donkey Hodie	11:00 am
3 TPTLF	The Key Ingredi...	08/07 10:00 am	New Scandinavian...	10:30 am	Pati's Mexican T...	11:00 am	Steven Raichlen...	11:30 am
4 TPTMN	Farm Fresh Roa...	08/07 11:00 am	Minnesota: A History of the Land	10:30 am	Off 90	11:00 am	MN Original	11:30 am
5 KSTP	Minnesota Live	08/07 11:30 am	The View	10:30 am	5 Eyewitness News Midday	11:00 am	GMA3	11:30 am
9 KMSP	Fox 9 Good Day	08/07 12:00 pm	The Jason Show	10:30 am	FOX 9 News at 11 a.m.	11:00 am	Sherri	11:30 am
10 Fox9+	Hot Bench	08/07 12:30 pm	GMFB: Overtime	10:30 am	GMFB: Overtime	11:00 am	Equal Justice W...	11:30 am
11 KARE	Today 3rd Hour	08/07 1:00 pm	Today with Jenna & Friends	10:30 am	Live With Kelly and Mark	11:00 am	KARE 11 News...	11:30 am

## Future Program Options in TV Guide

Here are the options for programs airing in the future.




## Restart TV that You Missed

You can scroll back up to 24 hours in the TV Guide to watch or record a program you may have missed. The main Menu also has a “Restart TV” list of all the programs available to restart in the past 24 hours listed by channel number.




## Program Options While Watching TV

While watching a program (live or replay), press the “OK” button to display all your options.



- 123 – displays a numeric keypad to enter the CH #



- REC – record options
- Start this program over from the beginning
- Tune last channel
- EPG – TV Guide
- CC – Closed Captioning


Remote arrow down to display more content:

- What's On
- Trending programs
- Last 10 Channels Tuned
- Your Recordings

## How to Record

1. You can record the program you are watching live, as described above. You can record one episode or a series.
2. From the TV Guide, you can schedule to record a future program or go back in the TV Guide up to 24 hours to watch or record a program.

**NOTE: DVR recording capacity is 30 hours and recordings auto-delete in 7 days.**




## Settings

From the Main Menu, select Settings to display these options.




## Create Favorite Channel Lists

Create as many favorite channel lists as you want.



## How to See Your Favorite Lists

Select “Channels” from the Main Menu to display the left screen view below. After you create favorite channel lists, for example “SPORTS”, you can switch to display your favorite “SPORTS” channel list here. Switch the list by using the remote left/right arrows.




## Changing Your Favorite Lists

While viewing your favorite list, press and hold the “OK” button to display the screen below. You can remove this channel from your favorites list.



While viewing All Channels, press and hold the “OK” button to display the screen below. You can add this channel to your favorites list.



## How to See the TV Guide with Your Favorite Lists

Select “Guide” from the Main Menu to display the view below. While viewing the TV Guide, press and hold the “BACK” button for 3 seconds and then release it. You should now see the names of your favorite lists appear at the top of the screen. Use the left/right arrows on the remote to select the favorite list you would like to populate the guide with and then press “OK”.

